


KG Remote Key Safe Microswitch Installation







M2.5 x 10 Set Screw



8mm HSS Drill Bit M2.5 TAP 2mm HSS Drill Bit

A fantastic and well priced safe that will manage the access and usage of all your important & critical keys.





Step 1.

Mark out the position of the DC1C-C3LB Micro Switch fixing holes onto the KG Remote Key Safe Body 24mm back from the inside edge of the flange and 47mm & 57mm from the edge of the safe body





Step 2.

Drill the marked holes 2mm dia with a HSS drill bit.





Step 3.
Tap the 2mm holes M2.5





Step 4.
From the LH Side mark back 32mm back from the flange and 8mm down from the top of the safe body.





Step 5.

Drill the marked hole using an 8mm dia HSS drill bit through both the LH outer safe body and the internal partition (make sure there are no wires in the area you are drilling)





Step 6.





Step 7

Fix the DC1C-C3LB Micro Switch to the key safe body using two M2.5 x 10mm Set Screws

